

Breit instructions

When fully charged, the battery lasts about 40 minutes
Temperature range 140 - 224 °C

OLED display:

Under normal circumstances, it shows the battery status, given the final or the heating temperature. "Low voltage" appears on the display if the battery is low.

-The red light flashes 10 times, "Low voltage" appears on the display if the battery reaches the end of its capacity during session, then the device switches off automatically.

-The red light flashes 5 times and the display shows "low voltage" if the device is in heating mode and then switches off automatically.

Charging: it is recommended to fully charge. The blue indicator light flashes for the duration of charging and remains flashing for the entire charge.

Charging time 1-1.5 hours, it is not recommended to charge longer in order to prevent the device from overheating.

Operate the vaporizer when it is cold. Remove the mouthpiece, insert the dried, slightly crushed herb into the chamber. It is important that the chamber is not too crowded, but at the same time not half-empty to achieve the best effect. Do not put any stems or seeds into the chamber.

To switch on the appliance, press the main button located above the temperature adjustment buttons 5 times in succession. When switched on the device heats up to the last selected temperature thanks to the internal memory. Then you can adjust the temperature to your specific one using the plus / minus buttons. It can be set in one step. The blue light flashes during heating and stays on when the desired temperature is reached.

After 5 minutes of not using, the device switches off automatically. To switch on again, quickly press 5 in succession. You can also turn off the device in the same way if you vaporize for less than 5 minutes.

If you press the main button for 3 seconds, you can change the temperature setting from degrees Celsius to Fahrenheit.

The appliance should be completely cool during cleaning. Make sure it is turned off.

The package includes a cleaning tool (see the picture in the manual) you will use to clean the chamber. Clean the mouthpiece with 90% alcohol and a cotton swab. Unscrew the internal filter from the mouthpiece and immerse it in alcohol for a few minutes to wet the deposits.