

1 COMPONENTS

1. Glass Attachment

2. Quick-Connect Adapter

3. Boost Evo

4. Airflow Release

5. Charger Indication LEDs

6. Charging Port (USB-C)



2 ON/OFF

- Press the power button five (5) times to turn On/Off.

3 CHANGE TEMP SETTING

- Press the power button three (3) times to change the battery temp setting.
- The temperature setting can be adjusted during heating to adjust the temperature quickly.
- Lower temperature settings are recommended for maximizing flavor, and higher temperatures are recommended for maximizing vapor production.

TEMP SETTINGS

SETTING	TEMP (°F)	LED
Temp 1	500	●
Temp 2	550	●
Temp 3	600	●
Temp 4	650	●
Temp 5	700	●
Temp 6	750	○

NEED MORE HELP? Visit www.drdabber.com/pages/boost-evo-support

dr.dabber

1.855.362.3227

INFO@DRDABBER.COM

WWW.DRDABBER.COM

@DRDABBER



4 OPERATING

- Remove glass attachment from the unit and load it from the top with water.
- Remove the quick-connect adapter with the glass attachment when loading material or removing atomizer.
- Place the quick-connect adapter back on the unit when ready to use.
- Press and hold button for three (3) seconds to start heating.
- Press and hold the airflow release button when ready to clear the chamber.

5 PARTY MODE

- While the unit is Off, press and hold the power button to change the time the unit stays on temperature.
- The LEDs will blink two (2) times to indicate a hold time of 20 seconds, or four (4) times to indicate a hold time of 40 seconds.

6 CHARGING

- The charger LEDs indicate the battery status.
- Charge Boost Evo with included cable. The Charger Indication LEDs will pulse white to indicate charging, and solid white to indicate fully charged.
- Blinking temperature color three (3) times indicates a low battery.

7 GLOW MODE

- Press the power button four (4) times to turn the Glow Mode On/Off.
- In Glow Mode, the LEDs will illuminate in a decorative pattern.
- Press the power button two (2) times to cycle between the five patterns.

8 STEALTH MODE

- Press the power button two (2) times while Glow Mode is off to turn Stealth Mode On/Off.
- LED illumination is reduced when using Stealth mode.

9 CLEANING

- Separate the quick-connect adapter, the atomizer, and glass attachment before cleaning. The atomizer is held in magnetically, pull up to remove.
- Clean the Atomizer and the Glass Attachment with up to 91% isopropyl alcohol. Clean the Boost Evo and the quick-connect adapter with up to 75% isopropyl alcohol. Do not submerge the atomizer, quick-connect adapter, or Boost Evo fully into isopropyl alcohol. Let all components fully dry before use.

10 RECALIBRATION

- When purchasing a new atomizer, the unit must be recalibrated with the new atomizer for accurate temperature readings.
- Turn unit Off and unplug from charger for 15 minutes before recalibrating.
- While the unit is OFF, press the button four times and keep holding the button on the fourth press to recalibrate the unit.
- A successful recalibration is indicated by Lights blinking White. If Lights blink Red, recalibration needs to be conducted again.

11 WARRANTY

- The Dr. Dabber Boost Evo has a 1 Year Warranty*
- If you have an issue with a defective or malfunctioning product, you can reach out to our award winning customer service team by email, phone or live chat. We are available between 9am-5pm PST Monday to Friday.

*Warranty not applicable to Glass attachment and Atomizer

12 SAFETY INFORMATION

Our products are intended for use by persons of legal age, not by children, women who are pregnant or breastfeeding, or persons with or at risk of heart disease, high blood pressure, hypertension, diabetes, or taking medicine for depression or asthma. Discontinue use and consult a physician if you experience symptoms such as nausea, vomiting, dizziness, diarrhea, weakness, rapid heart-beat or hypertension.



**boost
EVO**

USER GUIDE