



Instructions For Use:

1. Register S/N at bottom of packaging or top of Micro+ Battery at GOPEN.COM/REGISTER.
2. Fully charge G Pen Micro+ Battery from USB-C charging port located at bottom of device:
 - Button LED will flash **RED** while charging
 - Button LED will turn solid **GREEN** when fully charged
 - Button LED will flash five times when battery is low
 - Button LED will flash **RED** and **GREEN** five times when there is a tank connection issue
3. Press button five times to power ON / OFF Micro+ Battery.
4. The Micro+ Battery adjusts power output based on connection to a Micro+ Tank or any 510 cartridge using Cartridge Recognition Technology. Press button three times to toggle heat/voltage output settings.
5. For connection to the Micro+ Tank:
 - **Blue** = Low Heat
 - **Green** = Medium Heat
 - **Red** = High Heat
6. For connection to a 510 Cartridge:
 - **Blue** = 2.5V
 - **Green** = 2.75V
 - **Red** = 3V
7. Manual Heating: Hold button down to activate manual heating. LED will flash during heat-up and turn solid once the preset temperature is reached.
8. Automatic Heating: Press button twice to activate automatic heating. LED will flash during heat-up and turn solid once preset temperature is reached.
9. Inhale from mouthpiece once the LED turns solid.
10. Once preset temperature is reached, active heating can continue for a maximum duration of 10 seconds before automatically shutting off
11. Device will power off automatically after 5 minutes of inactivity.
12. Cleaning & Maintenance:
 - a. The ceramic airpath in the Micro+ Mouthpiece can be separated from the silicone sleeve and cleaned.
 - b. To clean and/or replace the Micro+ Tank, twist off mouthpiece assembly from the battery, then twist off Micro+ Tank.
13. ***HOT SURFACE WARNING***: Do not remove tank cover and/or handle Micro+ Tank for five minutes after use.

